

Safety Warnings



READ AND SAVE ALL INSTRUCTIONS BEFORE ASSEMBLING AND USING THIS PRODUCT. TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS, OBSERVE THE FOLLOWING:

1. Read all instructions before assembling and using this product.
2. Use this product only on a stable, level surface. Secure the wheels to prevent tipping or shifting.
3. Keep children and pets away during assembly and operation. This product is not a toy.
4. Do not allow anyone to climb, stand, or sit on the tank.
5. Pinch hazard: keep fingers clear of joints and connectors while assembling and disassembling.
6. Do not exceed the maximum load capacity of the tank.
7. Do not operate this product if it is torn, structurally damaged, or if any frame components are bent, cracked, or missing. Replace damaged parts before use.
8. Do not modify this product. Use only compatible accessories and replacement parts.

Manufacturer: AC Infinity Inc., 21880 Baker Parkway, City of Industry, CA 91789 USA
EU Representative: THEMIS AR Unterstützung UG (haftungsbeschränkt), Beedstraße 54, 40468 Düsseldorf, Germany, legal@themisar.com

1

Sicherheitswarnungen



LESEN UND BEWAHREN SIE ALLE ANWEISUNGEN AUF, BEVOR SIE DIESES PRODUKT AUFBAUEN UND VERWENDEN, UM DAS RISIKO VON BRAND, STROMSCHLAG ODER VERLETZUNGEN ZU VERRINGERN, BEACHTEN SIE FOLGENDES:

1. Lesen Sie alle Anweisungen, bevor Sie dieses Produkt aufbauen und verwenden.
2. Verwenden Sie dieses Produkt nur auf einer stabilen, ebenen Fläche. Sichern Sie das Zelt, um Umkippen oder Verrutschen zu verhindern.
3. Halten Sie Kinder und Haustiere während des Aufbaus und des Betriebs fern. Dieses Produkt ist kein Spielzeug.
4. Lassen Sie niemanden auf den Tank klettern, darauf stehen oder sitzen.
5. Quetschgefahr: Halten Sie Finger von Verbindungsstellen und Steckverbindungen fern, während Sie das Produkt auf- oder abbauen.
6. Überschreiten Sie nicht die maximale Traglast des Tanks.
7. Betreiben Sie dieses Produkt nicht, wenn es strukturelle Schäden aufweist oder wenn Komponenten verbogen, gebrochen oder fehlend sind. Ersetzen Sie beschädigte Teile vor der Verwendung.
8. Dieses Produkt darf nicht verändert werden. Verwenden Sie nur kompatibles Zubehör und Ersatzteile.

Hersteller: AC Infinity Inc., 21880 Baker Parkway, City of Industry, CA 91789 USA
EU-Vertreter: THEMIS AR Unterstützung UG (haftungsbeschränkt), Beedstraße 54, 40468 Düsseldorf, Deutschland, legal@themisar.com

2

Product Contents

RESERVOIR FILTER (AC-SWF5)



RESERVOIR HOPPER (x1)



WATER FILTER (x1)

WATER RESERVOIR (AC-SWR5)



WATER TANK (x1)



SILICONE PLUG (x2)



WHEEL CASTER (x4)



WATER STOPPER (F) (x1)



WATER STOPPER (M) (x1)



WATER TUBE (x1)

Product Contents

SELF-WATERING SYSTEM (AC-SWS5)



WATER TANK (x1)



SILICONE PLUG (x2)



WHEEL CASTER (x4)



WATER STOPPER (F) (x1)



WATER STOPPER (M) (x1)



TUBE SPLITTER (x3)



WATER TUBE (x1)



FABRIC POT (x4)



DRAIN PLATE (x4)



WATER BASIN (x4)



SUPPORT COLUMN (x4)



WICK LINE (x1)



AUTOMATIC WATER VALVE (x4)



VALVE CONNECTOR (x4)

Installation

Wheel Caster

STEP 1
Insert the casters into the holes at the bottom of the water tank.





STEP 2
You can lock the casters by pushing the tabs.

3

Installation

Self-Watering Base*

STEP 1
Place the support column in the center of the water basin.



STEP 2
Set the drain plate over the basin. Ensure the water valve's nozzle goes through the designated slot at the side of the drain plate.

STEP 3
Screw the valve connector and washer onto the automatic water valve's nozzle.

Do not overtighten.



*Included in the Self-Watering System (AC-SWS5)

4

Installation

Self-Watering Base*

STEP 1
Place the support column in the center of the water basin.



STEP 2
Set the drain plate over the basin. Ensure the water valve's nozzle goes through the designated slot at the side of the drain plate.

STEP 3
Screw the valve connector and washer onto the automatic water valve's nozzle.

Do not overtighten.

*Included in the Self-Watering System (AC-SWS5)

5

Installation

Self-Watering Base

USING THE WICK LINES
Thread the wick lines through the drain plate's holes. Refer to the chart below. Make sure the ends of the wick lines reach the basin floor.



STEP 3
Screw the valve connector and washer onto the automatic water valve's nozzle.

Do not overtighten.


*Included in the Self-Watering System (AC-SWS5)

6

Installation

Self-Watering Base

USING THE WICK LINES
Thread the wick lines through the drain plate's holes. Refer to the chart below. Make sure the ends of the wick lines reach the basin floor.



STEP 3
Screw the valve connector and washer onto the automatic water valve's nozzle.

Do not overtighten.


*Included in the Self-Watering System (AC-SWS5)

7

Installation

Self-Watering Base

PLACING YOUR FABRIC POT
Set your fabric pot on top of the drain plate. Lift up your fabric pot when making adjustments. Twisting and rotating the fabric pot while it is resting on the self-watering base will pull the wick lines away from the water and disrupt the self-watering action.



STEP 3
Connect water stopper M to the valve connector's nozzle using a piece of the water tube.

Do not overtighten.



*Included in the Self-Watering System (AC-SWS5)

8

Installation

Assembling the Chain

PREPARATION
Cut the included water tube at your desired lengths.



STEP 3
Connect water stopper M to the valve connector's nozzle using a piece of the water tube.

Do not overtighten.

*Included in the Self-Watering System (AC-SWS5)

9

Installation







Assembling the Chain: Multiple Bases



10

Installation




Assembling the Chain: Multiple Bases



11

Installation




Maintenance



12

Installation




Maintenance



13

Installation

Maintenance



14

Installation

Maintenance



15

Installation


Expanding Your System



16

Installation

Expanding Your System



17

More Information

WARRANTY

Our warranty program is our commitment to you, the original customer, that products sold by AC Infinity Inc. will be free from defects for TWO YEARS from the date of purchase. If you have any issues with this product, contact us and we'll happily resolve your problem or issue a full refund!



WEBSITE | www.acinfinity.com
EMAIL | support@acinfinity.com
PHONE | 626-838-6399
HOURS | 9 am to 5 pm PST
ADDRESS | 21880 BAKER PARKWAY
CITY OF INDUSTRY, CA 91789

DEALERS
EMAIL | dealers@acinfinity.com
PHONE | 626-838-4666
HOURS | 9 am to 5 pm PST

MANUAL CODE SWS2603X1

COPYRIGHT © 2026 AC INFINITY INC. ALL RIGHTS RESERVED

No part of the materials including graphics or logos available in this booklet may be copied, photocopied, reproduced, translated or reduced to any electronic medium or machine-readable form, in whole or in part, without specific permission from AC Infinity Inc.

18

Self-Watering System

Quick Start Guide



19

AC INFINITY