



AUTOMATIC SPRAYER

AC INFINITY

WELCOME

Thank you for choosing AC Infinity. We are committed to product quality and friendly customer service. If you have any questions or suggestions, please don't hesitate to [contact](#) us. Visit www.acinfinity.com and click contact for our contact information.

EMAIL

support@acinfinity.com

WEB

www.acinfinity.com

LOCATION

Los Angeles, CA

MANUAL CODE WSA2412X1

PRODUCT

Automatic Sprayer 1L (Graphite)

Automatic Sprayer 1L (Frost)

Automatic Sprayer 2L (Graphite)

Automatic Sprayer 2L (Frost)

MODEL

AC-WSA10-B

AC-WSA10-W

AC-WSA20-B

AC-WSA20-W

UPC-A

819137023963

819137023970

819137023772

819137023765

MANUAL INDEX

Manual Index	Page 5
Product Warning	Page 6
Key Features	Page 7
Product Contents	Page 8
Using The Sprayer	Page 9
Cleaning	Page 12
Other AC Infinity Products	Page 14
Warranty	Page 15


PRODUCT WARNING



TO REDUCE THE RISK OF INJURY TO PERSONS OR DAMAGE TO PRODUCTS, OBSERVE THE FOLLOWING:

1. Read all instructions before installing and using this product.
2. Do not tip this product upside down or leave it on its side.
3. The handle and USB cable are NOT waterproof. Keep the port and cable dry and out of humid environments and extreme temperatures.
4. Do not attempt to hardwire this product. Performing any retrofitting actions may result in personal injury and/or electrical damage, and will void this product's warranty.
5. Do not point this product towards yourself, other individuals, or animals.
6. Do not use this product with strong acidic and alkaline solutions, or with combustible and flammable liquids.
7. Hot water is not recommended for use with this product.
8. Do not use this product outside of its intended purpose.
9. This product is not intended for the consumption of liquids.
10. Do not operate this product while its cable is damaged.
11. Confirm that the USB cable is securely connected to both ends when charging your product.
12. To avoid algae growth, do not leave the sprayer in the sun for an extended period of time.


KEY FEATURES



PRODUCT CONTENTS



AUTOMATIC
SPRAYER
(x1)



USB
CABLE
(x1)


USING THE SPRAYER

STEP 1

Twist off the spray handle and fill the tank with water or your preferred mix.

Do not fill past the top line.

Make sure the water or your preferred mix is clear of any debris before filling the tank.



STEP 2

Tightly twist the spray handle back onto the tank.




STEP 3

Press the power button to begin spraying.



Twist the nozzle to the left for a fine mist.
Twist the nozzle to the right for a strong jet.




USING THE SPRAYER

CHARGING THE SPRAYER

Plug the cable's USB-C connector into the port on the side of the handle.

Connect the cable's USB connector into a power source to charge the sprayer.



LIGHT INDICATORS

The power button will change color based on the sprayer's battery status.


- **RED LIGHT**
Battery is charging.
- **BLUE LIGHT**
Battery is fully charged.
- **FLASHING BLUE LIGHT**
Battery is low.
- **NO LIGHT**
Sprayer is in normal operation.



USING THE SPRAYER

KEEPING THE SPRAYER UPRIGHT


Do not tilt the sprayer on its side or upside down for long periods of time. This may cause leaking.



CLEANING

STEP 1


Twist off the spray handle, the nozzle, and the nozzle tip.



STEP 2

Remove the pressure tube from under the handle.

Wipe away any debris from the pressure tube's filter.




CLEANING

STEP 3

Soak the nozzle pieces, the pressure tube, and the tank with vinegar water.

Do NOT submerge the handle in water.
Wipe the interior of the handle with a soapy cloth.


Let each component dry before use.



AC INFINITY PRODUCTS


Humidity Dome

The humidity dome is designed to maintain moisture levels to create the ideal environment for seed germination. Each kit includes a base tray and seedling tray with a dome that is built with adjustable vents to control humidity levels. Height extender also included to provide a higher ceiling for propagation applications.




Fabric Pots

A set of gardening grow bags designed to create wider root networks and improve plant growth by air pruning roots while draining excess water. Features industry leading 500G thick nonwoven fabric sewn with metal rings to enable air-suspended hanging or twist tie passthrough for low stress plant training.



Net Cups

A set of long lasting, reusable net cups designed to promote stronger root structures and even drainage to achieve greater water and nutrient absorption. Features wide lips and durable netting that can withstand use with many soil-based and hydroponic media such as expanded clay pebbles, lava rocks, pumice, and rock wool.



Discover the latest innovations in environmental controls at acinfinity.com

WARRANTY

This warranty program is our commitment to you, the product sold by AC Infinity will be free from defects in manufacturing for a period of two years from the date of purchase. Commercial grow lights sold by AC Infinity receive a five year warranty period. If a product is found to have a defect in material or workmanship, we will take the appropriate actions defined in this warranty to resolve any issues.

The warranty program applies to any order, purchase, receipt, or use of any products sold by AC Infinity or our authorized dealerships. The program covers products that have become defective, malfunctioned, or expressively if the product becomes unusable. The warranty program goes into effect on the date of purchase. The program will expire two years from the date of purchase (five years from the date of purchase of commercial grow lights). If your product becomes defective during that period, AC Infinity will replace your product with a new one or issue you a full refund.

The warranty program does not cover abuse or misuse. This includes physical damage, submersion of the product in water, incorrect installation such as wrong voltage input, and misuse for any reason other than intended purposes. AC Infinity is not responsible for consequential loss or incidental damages of any nature caused by the product. We will not warrant damage from normal wear such as scratches and dings.

Contact our dealers department at dealers@acinfinity.com or (626) 838-4656 for more information about our dealers and distributors program. Contact our customer service department at support@acinfinity.com or (626) 923-6399 for product and warranty assistance. Our business hours are Monday through Friday, 9:00 am to 5:00 pm PST.



If you have any issues with this product, contact us and we'll happily resolve your problem or issue a full refund!

COPYRIGHT © 2025 AC INFINITY INC. ALL RIGHTS RESERVED

No part of the materials including graphics or logos available in this booklet may be copied, photocopied, reproduced, translated or reduced to any electronic medium or machine readable form, in whole or in part, without specific permission from AC Infinity Inc.

www.acinfinity.com